



## Lecture 09

# Design of Wall and Column Footings

By: Prof Dr. Qaisar Ali  
Civil Engineering Department

UET Peshawar

[drqaisarali@uetpeshawar.edu.pk](mailto:drqaisarali@uetpeshawar.edu.pk)



## Contents

- Introduction
- Types of Foundation
- Wall Footing
  - General
  - ACI Recommendations
  - Design Procedure
  - Examples



## Contents

- Isolated/Column Footing
  - General
  - ACI Recommendations
  - Design Procedure
  - Examples
- References



## Introduction

- The substructure, or foundation, is the part of a structure that is usually placed below the surface of the ground and that transmits the load to the underlying soil or rock.
- Function of a foundation is to transfer the structural loads from a building safely into the ground.
- Foundation is regarded as the most important component of engineered systems.




## Types of Foundations

- Foundations can be divided into two broad categories depending on the depth of foundation;
  1. **Shallow Foundations**
    - Load transfer occur at shallower depths.
    - Isolated, Wall, Combined, Mat footings.
  2. **Deep Foundations**
    - Load transfer occur at deeper depths.
    - Piles, drilled piers, drilled caissons



## Types of Foundations

- **Shallow Foundations**
  1. **Isolated Column Footing**
    - Isolated column footing carrying a single column is usually called spread footing.



**Spread Footing  
(Ordinary)**




## Types of Foundations


- **Shallow Foundations**

1. **Isolated Column Footing**

- Sometimes spread footings are stepped, or are tapered to save materials.



**Spread Footing  
(Tapered)**



**Spread Footing  
(Stepped)**




## Types of Foundations

- **Shallow Foundations**

2. **Wall Footing (Strip Footing)**

- Wall footings or strip footings display essentially one-dimensional action, cantilevering out on each side of the wall.





## Types of Foundations


- **Shallow Foundations**

3. **Combined Footing**

- A combined footing is a type of footing supporting two or more than two columns. There are two common configurations of combined footings:

1. Two Column Footing

- Such a footing is often used when one column is close to a property line.




## Types of Foundations

- **Shallow Foundations**

3. **Combined Footing**

2. Column Strip or Multiple Column Footing

- A combined footing may also be used if the space between adjoining isolated footings is small.





## Types of Foundations

- **Shallow Foundations**

- 4. **Mat Footing**


- A mat or raft foundation transfers the loads from all the columns in a building to the underlying soil.
    - Mat foundations are used when excessive loads are supported on a limited area or when very weak soils are encountered.
    - Mat footings are essentially inverted slabs and hence they have as much configurations as typical slab systems have.




## Types of Foundations

- **Shallow Foundations**

- 5. **Mat Footing**



**Mat Footing with Beams**




**Mat Footing without Beams**




## Types of Foundations

- **Shallow Foundations**

5. **Mat Footing**



Mat Footing with Drop Panels



Mat Footing with Column Capitals




## Types of Foundations

- **Deep Foundations**

6. **Pile Foundation**

- This type of foundation is essential when the supporting ground consists of structurally unsound layers of materials to large depths.
- The piles maybe either end bearing, skin friction, or both.





## Types of Foundations

- **Choice of Foundation**
  - The choice of foundation type is selected in consultation with geotechnical engineer.
  - Factors to be considered are:
    - Soil strength
    - Soil type
    - Variability of soil type over the area and with increasing depth
    - Susceptibility of the soil and the building to deflections.
    - Construction methods



**Following types of footing will be discussed in detail in the next slides:**

- 1. Wall Footing**
- 2. Isolated Column Footing**







# 1. Wall Footing



## General

- **Behavior:**
  - A wall footing behaves similarly to a cantilever beam, where the cantilever extends out from the wall and is loaded in an upward direction by the soil pressure.






## General

- **Behavior:**



- The wall footing has bending in only one direction, it is generally designed in much the same manner as a one way slab, by considering a typical 12-in. wide strip along the wall length
- The simple principles of beam action apply to wall footings with only minor modifications.



## General

- **Reinforcement:**

- Main reinforcement for flexure is placed at the bottom of the footing perpendicular to the wall along the short direction, as shown.
- Temperature reinforcement is placed at the bottom of the footing parallel to the wall along the long direction.





## ACI Recommendations

- **ACI Chapter 13**
  - ACI section 13.3 contains provisions for shallow foundations.




## ACI Recommendations

- **Required Footing Area**
  - Footing bearing area is calculated based on unfactored forces or service loads (ACI 13.3.1.1)
  - **Bearing Area,  $A_{req} = \text{Service Load} / q_e$**
  - Where Effective bearing capacity,  $q_e = q_a - W$   
( $W = \text{Weight of fill} + \text{weight of concrete footing}$ )
- **Bearing pressure for strength design of footing,  $q_u$ :**
  - $q_u = \text{Factored load on column} / A_{req}$



## ACI Recommendations

- **Design Considerations in Flexure**
  - The wall footing is designed like a beam or one way slab, by considering a typical 12-in. wide strip along the wall length.




## ACI Recommendations

- **Design Considerations in Flexure**
  - The maximum factored moment is calculated at critical section.

- For a footing supporting concrete wall, critical section is located at the face of the wall.  
(ACI 13.2.7.1)

$$M_u = \frac{q_u b k^2}{2}$$

Where  $b = 1$  foot






## ACI Recommendations

### • Design Considerations in Flexure

- The maximum factored moment is calculated at critical section.

- For a footing supporting masonry wall, critical section is located between the edge and the middle of the wall. (ACI 13.2.7.1)

$$M_u = \frac{q_u b \left(k + \frac{t}{4}\right)^2}{2}$$



## ACI Recommendations

### • Design Considerations in Flexure

- Minimum reinforcement Requirement,  $A_{smin}$  (ACI 7.6.1.1):

- For Grade 40,  $A_{smin} = 0.0020 bh$
- For Grade 60,  $A_{smin} = 0.0018 bh$

Where;  $b = 12$  inches and  
 $h =$  thickness of footing

- Maximum spacing requirement

- Maximum spacing =  $3h$  or  $18''$

- Clear cover

- Minimum  $3''$  clear cover must be provided to protect the bars from corrosion.



## ACI Recommendations

- **Design Considerations in Shear**
  - Only **one-way shear** or **beam shear** is significant in wall footing. Hence determining critical shear at critical section which is at a distance "d" from the face of support.




## ACI Recommendations

- **Design Considerations in Shear**
  - **Calculation of Critical shear at distance 'd'**

$$V_u = q_u b(k - d)$$

Where b is unit width equal to 1 foot





## ACI Recommendations

- **Design Considerations in Shear**
  - **Beam shear capacity ( $\Phi V_c$ )**

$$\Phi V_c = \Phi 2 \sqrt{f'_c} b d$$

Where b is unit width equal to one foot or 12 inch

$\Phi V_c$  should be equal to or greater than  $V_u$ , If  $\Phi V_c < V_u$ , the depth of footing is increased instead of providing any shear reinforcement.



## Design Procedure

- **The design involves the following steps:**
  - **Step # 01: Estimate the thickness of footing, h**  
Assume thickness h of the footing which must satisfy the shear requirements. (Min. thickness of wall footing = 6 in.).
  - **Step # 02: Calculate weight of fill + weight of concrete footing, W**  
$$W = W_{\text{conc}} + W_{\text{fill}}$$
  - **Step # 03: Calculate effective bearing capacity,  $q_e$**   
$$q_e = q_a - W \quad (q_a = \text{Allowable bearing capacity of soil})$$
  - **Step # 04: Calculate bearing area,  $A_{\text{req}}$**   
$$A_{\text{req}} = \text{service load} / q_e$$



## Design Procedure

- The design involves the following steps:
  - Step # 05: Calculate design pressure on base of footing due to factored loads,  $q_u$

$$q_u = \text{Factored load} / \text{Bearing area}$$

- Step # 06: Calculate the critical shear,  $V_u$

$$V_u = q_u b (k - d)$$

- Step # 07: Check the shear capacity,  $\Phi V_c$

$$\Phi V_c = \Phi 2 \sqrt{f'_c} b d$$

$\Phi V_c$  shall be equal to or greater than  $V_u$ , if  $\Phi V_c < V_u$ , increase thickness of footing;  $b = 12$  inch



## Design Procedure

- The design involves the following steps:
  - Step # 08: Calculate maximum moment,  $M_u$

$$M_u = \frac{q_u b \left(k + \frac{t}{4}\right)^2}{2} \quad (\text{Masonry wall}) \quad \text{where; } t = \text{wall thickness}$$

$$M_u = \frac{q_u b k^2}{2} \quad (\text{Concrete wall})$$

- Step # 09: Calculate steel area,  $A_s$

$$A_s = M_u / \Phi f_y (d - a/2), \quad a = 0.2h$$

By trial and success method, find  $A_s$





## Design Procedure

- **The design involves the following steps:**
  - **Step # 10: Minimum reinforcement check**
    - $A_{smin} = 0.0020 bh$  For Grade 40
    - $A_{smin} = 0.0018 bh$  For Grade 60
  - **Step # 11: Main Bars Spacing and maximum spacing check**
    - Main Bars: Spacing =  $A_b \times 12 / A_s$
    - Maximum spacing = 3h or 18"



## Design Procedure

- **The design involves the following steps:**
  - **Step # 12: Distribution Bars Placement**
    - Distribution Bars will be provided along the long direction. Number of distribution bars will be calculated as follows:
 
$$\text{No. of bars} = A_{dist} / A_b$$
      - $A_{dist} = \text{Area of distribution Steel} = 0.0020 bh$  (For Grade 40)
      - $A_{dist} = 0.0018 bh$  (For Grade 60)
      - where; b = width of footing (inches), h = footing thickness (inches) and  $A_b$  = Area of bar to be used (in<sup>2</sup>)
  - **Step # 13: Drafting**



## Example 9.1


- **Design Example: Wall Footing**

- A 12-in thick concrete wall carries a service dead load of 10 kips/ft and a service live load of 12.5 kips/ft. The allowable bearing capacity,  $q_a$ , is 5000 psf at the level of the base of the footing, which is 5 ft below the final ground surface. Design a wall footing using  $f'_c = 3500$  psi and  $f_y = 60,000$  psi. The density of soil is 120 lb/ft<sup>3</sup>.



## Example 9.1

- **Design Example: Wall Footing**





## Example 9.1

- **Step # 01: Estimate the thickness of footing, h**
  - Assuming a trial thickness,  $h = 12$  in.
  - Effective depth,  $d = 12 - 3$  in. cover  $- \frac{1}{2}$  (bar diameter)  $\approx 8.5$  in.
- **Step # 02: Calculate weight of fill and weight of concrete, W**
  - $W = W_{\text{conc}} + W_{\text{fill}} = 1 \times 0.15 + 4 \times 0.12 = 0.63$  ksf
- **Step # 03: Calculate effective bearing capacity,  $q_e$** 
  - $q_e = q_a - W$
  - $q_e = 5 - 0.63 = 4.37$  ksf



## Example 9.1

- **Step # 04: Calculate bearing area,  $A_{\text{req}}$** 
  - $A_{\text{req}} = \text{service load} / q_e$
  - Service load =  $10 + 12.5 = 22.5$  kips/ft
  - $A_{\text{req}} = 22.5/4.37 = 5.15$  ft<sup>2</sup> per foot of length
  - Trying a footing 5 ft 2 in. wide
- **Step # 05: Calculate design pressure on base of footing due to factored loads,  $q_u$** 
  - $q_u = \text{Factored load} / \text{Bearing area}$
  - Factored loads =  $1.2(10) + 1.6(12.5) = 32$  kips
  - $q_u = 32/5.17 = 6.19$  ksf




## Example 9.1

- **Step # 06: Calculate the critical shear,  $V_u$**

- Only one-way shear is significant in wall footing, hence determining critical shear at distance  $d$  from the face of support.

- $d = 12 - 3 \text{ in. cover} - \frac{1}{2} \text{ (bar diameter)} \approx 8.5 \text{ in.}$
- $V_u = q_u b(k - d)$
- $V_u = 6.19 \times 1 \{(25 - 8.5)/12\}$   
= 8.51 kips/ft



## Example 9.1

- **Step # 07: Check the shear capacity,  $\Phi V_c$**

- **Check the Thickness for Shear**

- Shear capacity,  $\phi V_c = \phi 2 \sqrt{f'_c} b d$   
=  $\{0.75 \times 2 \times \sqrt{(3500)} \times 12 \times 8.5\}/1000$   
 $\phi V_c = 9.05 \text{ kips}$

- Since  $\phi V_c > V_u$ , the footing depth is OK. Otherwise, chose a new thickness and repeat the previous steps.
- Using 12 in thick and 5 ft 2 in wide footing.



## Example 9.1

- **Step # 08: Calculate maximum moment,  $M_u$**

$$M_u = \frac{q_u b k^2}{2} = 6.19 \times 1 \times ((25/12)^2 / 2)$$


$$= 13.43 \text{ ft-kips per ft}$$

- **Step # 09: Calculate steel area,  $A_s$**

- Now, using trial and success method for determining  $A_s$ ,

$$A_s = M_u / \Phi f_y (d - a/2), \quad a = 0.2h$$

- $A_s = 0.390 \text{ in}^2 \text{ per foot.}$



## Example 9.1

- **Step # 10: Minimum reinforcement check**

- Min reinforcement

$$A_{s,min} = 0.0018bh = 0.0018 \times 12 \times 12 = 0.26 \text{ in}^2/\text{ft}$$

$$A_s (0.390 \text{ in}^2) > A_{s,min} (0.26 \text{ in}^2) \text{ O.K.}$$

- **Step # 11: Main Bars Spacing and maximum spacing check**

- Main Bars: Spacing =  $A_s \times 12 / A_s$

$$\text{Using \#5 bars, spacing} = 0.31 \times 12 / 0.390 = 9.53 \approx 9 \text{ in. c/c}$$

- Max spacing =  $3h \text{ or } 18'' = 3(12) = 36'' \text{ or } 18'' \text{ (OK)}$



## Example 9.1


### • Step # 12: Distribution Bars Placement

- Distribution Bars:
  - $A_{dist} = 0.0018Bh = 0.0018 \times 62 \times 12 = 1.34 \text{ in}^2$ ,
  - No. of bars =  $A_{dist} / A_b = 1.34 / 0.31 = 4.32 \approx 5 \text{ bars}$



## Example 9.1

### • Step # 13: Drafting





## Example 9.2

- **Design Example: Wall Footing**
  - A 12-in thick concrete wall carries a service dead load of 15 kips/ft and a service live load of 10 kips/ft. The allowable bearing capacity,  $q_a$  is 5000 psf at the level of the base of the footing, which is 5 ft below the final ground surface. Design a wall footing using  $f'_c = 3000$  psi and  $f_y = 40,000$  psi. The density of soil is 120 lb/ft<sup>3</sup>.




## 2. Isolated Column Footing



## General

- **Shape:**
  - Individual column footings are generally square in plan.
  - Rectangular shapes are sometimes used where dimensional limitations exist.



**Spread Footing  
(Ordinary)**



## General


- **Behavior:**
  - The footing is a slab that directly supports a column.
  - Isolated footings display essentially two-dimensional action, cantilevering out on both orthogonal sides of the column.
  - The footing is loaded in an upward direction by the soil pressure.
  - Tensile stresses are induced in each direction in the bottom of the footing.






## General

- **Reinforcement:**
  - A spread footing will typically have reinforcement in two orthogonal directions at the bottom of the footing for flexure.



## General

- **Required Footing Area**
  - Bearing Area,  $A_{req} (B \times L) = \text{Service Load} / q_e$





- **$q_u$  (bearing pressure for strength design of footing):**
  - $q_u = \text{factored load on column} / A_{req}$



## ACI Recommendations

### • Design Considerations in Flexure

- The maximum factored moment is calculated at critical section.
  - For an isolated footing, critical section is located at the face of the column.
  - $M_u = q_u B k^2 / 2$ , where;  $k = (B - C) / 2$



## ACI Recommendations

### • Design Considerations in Flexure

- Minimum Reinforcement ( $A_{smin}$ ):
  - $A_{smin} = 0.005 B d_{avg}$
- Maximum Spacing Requirement (ACI 7.7.2.3):
  - Least of  $3h$  or  $18''$



## ACI Recommendations

- **Design Considerations in Shear**
  - The footing thickness (depth) is generally established by the shear requirement.
  - The footing is subjected to two-way action. The two-way shear is commonly termed Punching shear, since the column or pedestal tends to punch through the footing, induces stresses around the perimeter of the column.
  - Beam shear is not usually a problem in an isolated footing.



## ACI Recommendations

- **Design Considerations in Shear**
  - Two-Way Shear (Punching Shear)
  - The critical section for this two-way shear is taken at  $d/2$  from the face of the column.





## ACI Recommendations

- Design Considerations in Shear
  - Calculation of Critical shear at distance  $d/2$

$$V_{up} = q_u B^2 - q_u (c + d_{avg})^2$$

$$V_{up} = q_u \{B^2 - (c + d_{avg})^2\}$$




## ACI Recommendations

- Design Considerations in Shear
  - Punching shear capacity ( $\Phi V_{cp}$ )

$$\Phi V_{cp} = \Phi 4 \sqrt{f'_c} b_o d_{avg}$$

Where  $b_o$  is Critical Shear Parameter,  $b_o = 4 \times (c + d_{avg})$





## ACI Recommendations

- **Design Considerations in Shear**

$\Phi V_{cp}$  should be equal to or greater than  $V_{up}$ . If  $\Phi V_{cp} < V_{up}$ , the depth of footing is increased instead of providing any shear reinforcement.



## Design Procedure

- **The design involves the following steps:**

- **Step # 01: Estimate the thickness of footing, h**

Assume thickness h of the footing which must satisfy the shear requirements. (Min. thickness of footing on soil = 6 in.). Also find 'd'.

- **Step # 02: Calculate weight of fill + weight of concrete, W**

$$W = W_{conc} + W_{fill}$$

- **Step # 03: Calculate effective bearing capacity,  $q_e$**

$$q_e = q_a - W \quad (q_a = \text{Allowable bearing capacity of soil})$$

- **Step # 04: Calculate bearing area,  $A_{req}$**

$$A_{req} = \text{service load} / q_e$$



## Design Procedure

- The design involves the following steps:

- Step # 05: Calculate critical shear parameter,  $b_o$

$$\text{Critical Perimeter, } b_o = 4 \times (c + d_{avg})$$

- Step # 06: Calculate design pressure on base of footing due to factored loads,  $q_u$

$$q_u = \text{Factored load} / \text{Bearing area}$$

- Step # 07: Calculate the punching shear force,  $V_{up}$

$$V_{up} = q_u \{B^2 - (c + d_{avg})^2\}$$



## Design Procedure

- The design involves the following steps:

- Step # 08: Check the punching shear capacity,  $\Phi V_{cp}$

$$\Phi V_{cp} = \Phi 4 \sqrt{f'_c} b_o d_{avg} \quad \Phi V_{cp} \geq V_{up}$$

$\Phi V_{cp}$  shall be equal to or greater than  $V_{up}$ , if  $\Phi V_{cp} < V_{up}$ , increase thickness of footing

- Step # 09: Calculate maximum moment,  $M_u$

$$M_u = q_u B k^2 / 2, \quad \text{where; } k = (B - C) / 2$$

- Step # 10: Calculate steel area,  $A_s$

$$A_s = M_u / \Phi f_y (d - a/2), \quad a = 0.2 d_{avg} \quad \text{By trial and success method, find } A_s$$



## Design Procedure

- **The design involves the following steps:**
  - **Step # 11: Minimum reinforcement check,  $A_{smin}$** 

$$A_{smin} = 0.005Bd_{avg}$$
  - **Step # 12: Bars Placement**
  - **Step # 13: Drafting**



## Example 9.3

- **Design of a square column footing**

A column 18" square with  $f'_c = 3$  ksi reinforced with 8 #8 bars of  $f_y = 40$  ksi, supports a service load of 81.87 kips ( factored load = 103.17 kips). The allowable soil pressure is 2.204 k/ft<sup>2</sup>. Design a square footing with base 5' below surface. Take unit weight of soil as 100 pcf.



## Example 9.3

- **Data Given:**


- Column size = 18" × 18"
- $f'_c = 3$  ksi
- $f_y = 40$  ksi
- $q_a = 2.204$  k/ft<sup>2</sup>
- Factored load on column = 103.17 kips (Reaction at the support)
- Service load on column = 81.87 kips (Reaction at the support due to service load)



## Example 9.3

- **Step # 01: Estimate the thickness of footing, h**

- Assume  $h = 15$  in.
- $d_{avg} = h - \text{clear cover} - \text{one bar dia}$   
 $= 15 - 3 - 1(\text{for \#8 bar}) = 11$  in.



- **Step # 02: Calculate overburden pressure, W**

- Assume depth of the base of footing from ground level ( $z$ ) = 5'
- Weight of fill and concrete footing,  $W = W_{conc} + W_{fill}$   
 $W = \gamma_{fill}(z - h) + \gamma_c h = 100 \times (5 - 1.25) + 150 \times (1.25)$   
 $W = 562.5$  psf = 0.5625 ksf





### Example 9.3


- **Step # 03: Calculate effective bearing capacity,  $q_e$**

- Effective bearing capacity,  $q_e = q_a - W$   
 $= 2.204 - 0.5625 = 1.642 \text{ ksf}$

- **Step # 04: Calculate bearing area,  $A_{req}$**

- Bearing area,  $A_{req} = \text{Service Load} / q_e$   
 $= 81.87 / 1.642 = 49.86 \text{ ft}^2$

$$A_{req} = B \times B = 49.86 \text{ ft}^2 \Rightarrow B = 7 \text{ ft.}$$



### Example 9.3


- **Step # 05: Calculate critical shear parameter,  $b_o$**

- Critical Perimeter,  $b_o = 4 \times (c + d_{avg})$   
 $= 4 \times (18 + 11) = 116 \text{ in}$

- **Step # 06: Calculate design pressure on base of footing due to factored loads,  $q_u$**

- $q_u = \text{factored load on column} / A_{req}$

$$q_u = 103.17 / (7 \times 7) = 2.105 \text{ ksf}$$






### Example 9.3

- **Step # 07: Calculate the punching shear force,  $V_{up}$**

- $V_{up} = q_u \{B^2 - (c + d_{avg})^2\}$
- $V_{up} = q_u B^2 - q_u (c + d_{avg})^2$
- $V_{up} = 2.105 [7^2 - \{(18+11)/12\}^2]$   
= 90.85 kip



### Example 9.3

- **Step # 08: Check the punching shear capacity,  $\Phi V_{cp}$**


- $V_{up} = 90.85$  kip

Punching shear capacity ( $\Phi V_{cp}$ )

$$\Phi V_{cp} = \Phi 4 \sqrt{f'_c} b_o d_{avg}$$

$$\Phi V_{cp} = 0.75 \times 4 \times \sqrt{3000} \times 116 \times 11/1000$$

$$\Phi V_{cp} = 209.66 \text{ k} > V_{up}, \text{ O.K}$$






### Example 9.3

- **Step # 09: Calculate maximum moment,  $M_u$**

- $M_u = q_u B k^2 / 2$
- $k = (B - C) / 2 = (7 \times 12 - 18) / 2$   
 $= 33 \text{ in} = 2.75'$
- $M_u = 2.105 \times 7 \times 2.75 \times 2.75 / 2$   
 $= 55.72 \text{ ft-k}$   
 $= 668.60 \text{ in-kip}$



**Critical Section for Flexure**



### Example 9.3

- **Step # 10: Calculate steel area,  $A_s$**

- $M_u = 668.60 \text{ in-kip}$      $a = 0.2d_{\text{avg}} = 0.2 \times 11 = 2.2''$   
 $A_s = M_u / \{\Phi f_y (d_{\text{avg}} - a/2)\} = 668.60 / \{0.9 \times 40 \times (11 - 2.2/2)\} = 1.87 \text{ in}^2$   
 $a = A_s f_y / (0.85 f_c' B) = 1.83 \times 40 / (0.85 \times 3 \times 7 \times 12) = 0.35''$   
After trials,  $A_s = 1.71 \text{ in}^2$



## Example 9.3

- **Step # 11: Minimum reinforcement check,  $A_{smin}$**

$$A_{smin} = 0.005 B d_{avg} = 4.62 \text{ in}^2$$


**$A_{smin} = 4.62 \text{ in}^2$  so  $A_{smin}$  governs**



## Example 9.3

- **Step # 12: Bars Placement**


- Now, the spacing can be calculated as follows:
- Using #8 bars: No. of bars =  $4.62/0.79$   
 $\approx 6$  bars.
- Spacing =  $6.5 \times 12 / 5 = 15 \text{ in. c/c}$
- Hence 6 bars can be provided in the foundation if they are placed 15 in. c/c
- Max. spacing should not exceed 3h or 18 in





## Example 9.3

- **Step # 13: Drafting**



## Example 9.4

- **Design of a square column footing**

A column 18" square with  $f'_c = 3\text{ksi}$  reinforced with 8 #8 bars of  $f_y = 60\text{ksi}$ , supports a service dead load of 220 kips and a service live load of 175 kips. The allowable soil pressure is  $5\text{ k/ft}^2$ . Design a square footing with base 5' below surface. Take unit weight of soil equal to  $100\text{ pcf}$ .



## Assignment # 04

- Submit Example # 9.4 of Lecture 09-Design of Column and Wall Footings in the next class.



## Quiz # 04

- A short quiz will be taken in Lecture 08-Design of RC Column in the next class



## References

- Design of Concrete Structures 14<sup>th</sup> / 15<sup>th</sup> edition by Nilson, Darwin and Dolan.
- ACI 318-14